719 Coarse Medium Wall Filler



Product information

Beck & Jorgensen A/S

Directions for use

The substrate must be clean, dry and sound / stable and free from all substances that may prevent good adhesion. Remove dirt, dust and loose material. Wash down previously painted surfaces with appropriate detergent. Priming of porous and water absorbing surfaces with Microprimer 716 or semilar is recommended.

Cleaning instructions

Water

Safety & environment

Use eye and respiratory protection according to environmantal rules, an read MSDS for futher instructions.

Remarks

High film layer prolongs drying time

Technical data

Binder:

Type: Low Denisty Filler

Gloss: Vol. dry:

Colours: Grey

Drying: Aproxx 1 hour / mm at 20C og 65% RH

Application: +10 °C to + 25° C. RH: 40-80% **Thinning:** Water. Normally not to be diluted

Coverage: Aproxx 1 ltr./m²/mm
Tools: Spatual / trowel
Mal-Code: 00-1 (1993)



